

---

# Warranty

EasySlide desks come with a warranty of 2 years. The warranty period starts on the next day after your desk has been delivered to you. The warranty is only effective when the desk's installation guidelines have been followed during installation, when the product has been used as intended and when your EasySlide desk has been maintained according to the maintenance guidelines.

## What to do when something goes wrong?

To benefit from the warranty during the appropriate guarantee time frame, you want to inform ASKIA about the imperfections that have showed up in 2 weeks time after their development. To do that send a composed case to ASKIA, bringing up the following:

- the name of the absonded item or detail
- a definite depiction of the shortcoming/deformity
- a photograp and a video of the issue/deformity.
- receipt, conveyance note or any other proof of purchase.

The replaced /repaired products are subject to the same terms an conditions as the new products are. The warranty does not exclude or limit your right to use other remedies based on the law or on your contract.

Contact for warranty questions and customer support:  
contact@askiafurniture.ro  
Your warranty provider is: ASKIA FURNITURE SRL

## Active warranty

In order to be covered by the warranty, you have to maintain your Easy Slide desk at reasonable intervals. The warranty does not extend to the natural wear of the pod, or to the texture and shade differences in wooden surfaces when you have purchased your products or its details at different times (as an additional order).

## The warranty becomeds invalid

When maintenance work has benn undertaken on the Easy Slide desk during the official warranty period by a service provider who is not licenced by ASKIA.

- when details have been added to the Easy Slide desk which have not been approved by ASKIA.
- when the faults or defects have appeared due to wrongful maintenance, product's misuse, or during relocation of the assembled product.
- when the Easy Slide desk has been subjected to mechanical damage.

## How will it get fixed

During the active waranty period, ASKIA will repair or replace all defective details or products as fast as possible, but not latert than within 60 days after the written claim has been accepted by ASKIA. The delivery of replacement parts (that are covered by the warranty) is subject to similar conditions that were in effect during the original delivery of the product.

# Instructions

Easy Slide Collection is a family of desks and storage solutions pods that seats 1 - 12 people depending on the desk, and provides a versatile work space that can be configured in multiple ways depending on the customer's needs. Do not step on the countertop or otherwise put weight on the frame.

## Instructions for maintenance:

### Upholstery:

Remove dust with a vacuum cleaner with a fabric or upholstery attachment. Absorb any liquid spills with a paper towel and then wipe with a damp cloth and let the fabric dry. Clean up spills immediately after they happen.

### CLEANING MATRIX

	Vacuum	Extraction cleaning	Dry clean (if loses cover)	Washable up to 60°C
wool	x	x	x	
blends	x	x	x	
polyester	x	x	x	x
trevira CS	x	x	x	x

### DISINFECTION MATRIX

	Steam	Dry clean (if loses cover)	Alcohol based solution 70% / spray / wipes	Washable up to 60°C	Bleach – general disinfection: diluted 1:10 / spray and wipes
wool	x	x	x		x
blends	x	x	x		x
polyester	x	x	x	x	x
trevira CS	x	x	x	x	x

### SOLID WOOD, PLYWOOD and VENEER

Only use oil or wax-based cleaning products and only when damp. A damp cloth with catch the dust and create a silky smooth protective film to prevent further contamination and fluid intrusion. Do not leave mugs or glasses sitting on the desk and wipe up any spilled liquids immediately to prevent stains.

### CHIPBOARD + MELAMINE

Use a damp cloth to clean the entire surface. Use a microfiber cloth when dry dusting. Avoid direct sunlight and heat.